

# Barrier™

PROFESSIONAL  
LANDSCAPE EDGING

- Easy to Install
- Professional Results Fast at Do-It-Yourself Prices
- Use as Landscape Edging or as a Paver Edge Restraint
- No Trenching Required
- Hammer, Shovel and Cutters are the Only Tools Required
- Convenient Single Piece for Straight Runs, Sweeping Curves, or Tight Bends
- Quick and Permanent Connection Between Lengths
- Resists Frost Heaving
- Barrier Is Reusable - If the Design Changes, Simply Reinstall



**Interlock and spike ends together, ensuring a secure connection with extra support**



Snapedge Canada Ltd.  
1-800-720-SNAP (7627)

Visit our website for more information  
[www.snapedge.ca](http://www.snapedge.ca)



Made with recycled materials

Distributed by:

# Barrier™

PROFESSIONAL  
LANDSCAPE EDGING



**The Next Generation  
In Landscape Edging**

# Barrier™ Professional Landscape Edging creates a permanent barrier between many landscape materials, becoming invisible after installation

## Barrier™ Edging for Pavers

- Professional results at do-it-yourself prices
- Designed for use with concrete pavers & slabs
- Prevents pavers from moving horizontally
- Open base allows grass roots to help anchor edging
- Barrier becomes invisible after installation





TYPICAL PAVER INSTALLATION CROSS-SECTION



CIRCULAR WALKWAYS/PATIOS



STRAIGHT WALKWAYS/PATIOS



A 1" layer of coarse, dry sand is placed on top of the subbase using 1" diam. electrical conduit pipes as screed rails. Lay the pavers gently on the sand, being sure to place each paver firmly against its neighbors. Complete the laying process with whole pavers only.

After all whole pavers are in place, use a hand trowel to carefully remove the screeded sand beyond the paver area. Install Barrier Landscape Edging firmly against the pavers using 8" - 10" x 3/8" landscape spikes, spaced 18" apart. Using a mason diamond saw, cut


the paver pavers required and fill in all gaps. Using a broom, spread dry, coarse sand into joints between pavers. Do so until all joints are filled with sand. Backfill the border area around the project as soon as possible.

## Barrier™ Edging for Landscaping


- Ideal for creating a professional edge to your planting beds and gardens
- Perfect solution for building tree rings
- One length creates a 25" diameter ring, additional pieces connect to form larger rings
- Creates a permanent barrier between different landscape materials
- Holds landscape fabric and weed barriers firmly in place



LANDSCAPE INSTALLATION CROSS-SECTION




TREE RINGS




PLANTING BEDS


When creating curves, snip supports and bend. Spread or overlap the cut supports depending on whether you are creating an inside or outside curve.



INSIDE CURVE




OUTSIDE CURVE




INSTALLING BARRIER™ AS A TREE RING

When installing Barrier as a tree ring, remove the grass down to soil level. Snip supports and bend to form the proper border around the tree. Spike Barrier Landscape Edging in place using 8" - 10" x 3/8" landscape spikes, spaced 12" apart.



INSTALLING BARRIER™ WITH LANDSCAPE FABRIC

If landscape fabric is being used, remove all grass down to earth level in the desired landscape area. Lay the fabric over this area with excess extending in to the lawn. Place Barrier on top of the fabric and nail in place. Cover fabric with landscape fill and trim excess fabric with a knife.



HEAVY LAWN TRAFFIC OR TO MAKE BARRIER™ INVISIBLE

For greater stability or to make Barrier invisible, you can either remove 1" of earth below the intended installation area and spike Barrier in place in this lower position or you can add a 12" to 18" wide berm of dirt on the grass side which gradually slopes up to a depth of 1" deep or more against the Barrier.

For paving stone installations, Barrier™ is suitable for residential use only. For heavy duty or commercial applications use Snap Edge® paver restraint.